

# Recommended cleaning and disinfecting guidelines

## for your radios, body-worn cameras and accessories

**NORAKOM**<sup>®</sup>  
NORSK RADIOKOMMUNIKASJON AS



In response to the coronavirus (COVID-19) pandemic, here are some guidelines how to keep your radios, body-worn cameras and accessories cleaned and disinfected.

### General Cleaning:

- Apply 0.5% detergent-water solution with a cloth, then use a stiff, non-metallic, short-bristled brush to work all loose dirt away from the device. Use a soft, absorbent, lintless cloth or tissue to remove the solution and dry the device.
- Make sure that no solution remains entrapped near any connectors, cracks or crevices.

### Disinfecting:

- Devices may be disinfected by wiping them down with over-the-counter isopropyl alcohol (rubbing alcohol) with at least 70% alcohol concentration.
- When cleaning with isopropyl alcohol, the alcohol should never be applied directly to the device. It should be applied to a cloth, which is then used to wipe down the device.
- The effects of certain chemicals and their vapors can have detrimental effects on plastics and the metal platings.

**Do not** use bleach, solvents or cleaning sprays to clean or disinfect your device.

Ref.: Motorola Solutions, Technical Notification,  
MTN-0038-20-GL, 03-2020

## Protect yourself and others

### Prevent infection



Cough or sneeze into  
your sleeve



Limit physical  
contact



Wash your hands frequently or  
use an alcohol-based hand rub



Be diligent  
with cleaning



Avoid crowds of people  
and keep distance